

INSTALLATION GUIDELINES

The following installation instructions must be followed for warranty purposes and for optimal performance. InStone does not install panels or have control over the installation of the panels, therefore these Installation Instructions are to be used as guidelines. Quality Stone panels are for outside (exterior) use only unless panels are ordered as 'Interior' using our Class A fire-rated poly. It is the responsibility of the installer to ensure all products are installed in accordance with the Quality Stone Installation Instructions. InStone assumes no liability for improper installation or personal injury resulting from proper or improper use or installation.

SAFETY FIRST

The operator of any power tools or other tools should be skilled and familiar with the correct use of each tool. Proper safety gear must always be worn.

BUILDING CODE

Follow local Building Codes when installing. Quality Stone products are for exterior use only, unless ordered otherwise. It is the responsibility of the installer to ensure that applicable building codes are met or exceeded. Like other siding products, for exterior use a weather barrier (Tyvek, Typar, tar paper, etc) must be put on top of the wood substrate, before applying Quality Stone.



RECOMMENDED TOOLS:

Miter Saw and/or Table Saw	Drill	Measuring Tape	Pencil	Level
10 oz. Caulking Gun	Stagger Stencil	Drywall Saw	Utility Knife	
Safety Glasses	Earplugs	Dust Mask		

HANDLING AND STORAGE OF PRODUCTS:

Quality Stone products are highly impact resistant once they are installed but should be handled carefully to reduce damage prior to installation. The products should be laid flat and kept out of direct sunlight or they may be susceptible to warping. Exposed polyurethane will yellow in the sun. Ensure exposed areas are covered with the recommended Stone Finish to protect from UV. Different climates will also have a movement affect (expansion and contraction) in polyurethane products.

Quality Stone has been designed to best adapt to this change, but it is always best to install when panels are cool– please ask representatives for the best stone fit for your application.

Unless ordered in Class A poly for intended solely for interior use, the Product can only be installed on an exterior (outside) of a house/building.

PRODUCT COLORING:

Please ensure that the production dates on all products being installed side-by-side are the same. This will help ensure consistent coloring. Most of the time product from different dates will match up, but the installer should check this before installing. There is the possibility for a panel to be slightly off colored in a batch. Again, check all panels match before installing.

For more information, please visit our website or contact us:

www.qualitystoneproducts.com * Toll Free at 1-877-477-4373 * Email at info@instoneproducts.ca

INSTALLING PANELS:

Quality Stone can be installed working in either direction. In the rare case that you are working between two walls, it is recommended to work from right to left for an easier installation. Each of the stone profiles has 4 different patterns or panels, each of which is numbered accordingly. Effort should be made to keep same-numbered panels away from one another (you do not want them beside one another or on top of one another). Optimally, they should be installed 1-2-3-4, and if there is a row above this one – they should be installed 4-3-2-1, etc.

The wall should first be measured and laid out, and a level line should be set prior to installing the starter strips. After the wall is laid out, place and fasten the corner(s) first. Then measure the distance remaining between the last panel and the wall. Measure and cut the panel the correct length (using the Stagger Stencil). Put Stone Finish caulking on the cut edge to cover the exposed polyurethane. Then cut the tongue off the panel that will meet up to the new cut piece. Place the panel in its designated position to check the fit. Ensure the Stone Finish has created a seal between the panels.

Begin each next row with the cut panel from the previous row. This will ensure random joint staggers and eliminate waste. The top row will also need to be cut lengthwise (ripped) to the necessary height, so the panel fits flush with the ceiling or top of the wall.

INSTALLING CORNER PANELS:

Quality Stone recommends using Corner Panels rather than mitering. For best results, alternate Left and Right Corner Panels on each course, which ensures the joints are staggered, giving the best look. Corner Panels are applied the same as Panels, with screws going in the top tongue of the panel. Corner Panels should be installed using a minimum of 3 screws.

***IMPORTANT - Make sure to use a Panel or another Corner Panel as a spacer when installing the Left Corner Panels. If this is not done, the return on the Corner Panel will be too tight to the wall, and the tongue of the adjoining Panel will not have a groove to fit into**.*

MITERING CORNERS

For an interior installation, a miter can also be cut using regular Panels and a miter saw. If mitering on an exterior application expansion and contraction can cause the cut pieces to separate. (Opening up of cut corners is not covered under warranty). Cuts should be very tight, and then Stone Finish and Touch Up Paint applied in combination to ensure long-term color match. If there is a gap, a screw(s) can be used to fasten the two cut pieces together prior to caulking.

To fit a 90-degree inside or outside corner, cut each end at a 45-degree angle and try for no gap, and apply the caulking. Both cuts should be made at the same place on the same panel to help ensure the stone matches on both sides of the corner.

If there is a gap, tighten screws or nails and fill unwanted gaps with Stone Finish and/or Quality Stone Paint Kit.

INSTALLING LEDGE TRIMS:

In most applications, the Ledge Trims will be sitting on top of an already installed panel. Screws should be applied directly through the face (*not the top) using 3½" - 4" screws every 8". Stone Finish and Touch-Up Paint should be applied to cover any screw holes.

*If a metal flashing is being installed on top, screws can also be put into the top surface as it will be covered by the flashing.

INSTALLING TOP TRIMS:

In most applications, the Top Trims will be sitting on top of an already installed panel. Apply adhesive to the top of the panel below the trim and then place the Top Trim on top.

*If a metal flashing is being installed on top, screws can also be put into the top surface as it will be covered by the flashing.

INSTALLING EDGE TRIMS:

Wherever possible, Edge Trims should be applied prior to installing panels. Screws can be applied every 8" on the side of the trim facing the stone, at a 45-degree angle. This will ensure a strong fastening, and the panels that are installed against the Edge Trim will hide the screws. If panels do not hide the screws, use Stone Finish and/or Quality Stone Paint Kit to finish.

For more information, please visit our website or contact us:

www.qualitystoneproducts.com * Toll Free at 1-877-477-4373 * Email at info@instoneproducts.ca

INSTALLING SIDE TRIMS:

Side Trims are typically applied once all panels are installed. Apply adhesive to the side edge(s) of the installed panels, then slide the Side Trim so one side is behind the panel and the other side butts up to (and covers) the side of the panel with the adhesive.

INSTALLING FIXTURE TRIMS AND ELECTRICAL TRIMS:

These trims should be installed prior to installing any panels. Both the Fixture and Electrical Trims are applied by diagonally screwing 2 ½" – 3" screws through the sides, bottom, and top. This will allow for the surrounding panels, once installed, to conceal any screw holes. If for any reason the screw is still visible on the side, Quality Stone 'Stone Finish' caulking should be used to cover the screw.

APPLICATION OVER CONCRETE/BRICK:

Quality Stone can be applied according to the standard instructions above, with a couple of differences. A pilot hole can be drilled into the concrete with a masonry bit, and a special masonry screw should be used to fasten the product (no need for construction paper). In some cases, a wood or masonry screw can be applied directly into the concrete without pre-drilling a pilot hole.

A second option is to fasten a sheet of 1/2" or 3/4" plywood to the concrete and then to continue with normal wood substrate installation.

Adhesive (see below) can be used alone or in conjunction with the screws to ensure a solid installation.

Another method we recommend (if it is an option) is to spend the time to remove the brick. This will make for a much easier and faster installation and will give a good even surface to work from.

APPLICATION WITH RAINSCREEN:

Where rainscreens are required, we would strongly recommend more of the mat or mesh version rather than furring strips.

Quality Stone can be installed over furring strips, but it is just very important that a strip is positioned where any two panels meet for proper support and fastening.

In addition, if the furring strips are too far apart, it can leave Quality Stone weaker due to the voids behind the product. If installed onto a furring mat, it is equally supported across the product, and there is no need to have bracing where any panels meet.

APPLICATION OVER EXISTING SIDING:

All siding should be carefully removed with suitable cutting tools (utility knife, reciprocation saw, etc.). Once this is complete, check to ensure that the construction paper beneath the siding is in good condition (if it is not, apply new paper). Then proceed with installation.

APPLICATION OVER ICF'S (INSULATED CONCRETE FORMS):

Use the standard installation instructions labeled above. The plastic 'webs' that are contained within the foam walls will act as a suitable anchor for the screws. Check with the ICF supplier to see whether applying construction paper before the stone installation is recommended. Adhesive (see below) can be used in conjunction with the screws to ensure a solid installation.

APPLICATION OVER GYPSUM BOARD (DRYWALL):

When installing over gypsum, the product must be fastened into the supporting framing wherever possible. Due to the spacing of the supporting framework, this will not always be possible. Coarse drywall screws into the gypsum help secure the panel as well.

Adhesive (see below) can be used alone or in conjunction with the screws to ensure a solid installation.

QUALITY STONE
EASY-INSTALL PANELS BY INSTONE

Installation Instructions

ADHESIVE:

Products can be fastened to concrete, brick or other hard surfaces using the proper construction adhesive. Quality Stone recommends using a heavy-duty construction adhesive like Titebond TiteGrab or Gorilla Glue. All surface areas must be clean, dry and free of oily and loose materials. Due to the smoothness of the back of Quality Stone products, the back should also be roughened to allow for better adhesion. If it is not rough enough, the adhesive may not hold.

Apply adhesive to the back perimeter of the product, and then fill in with a serpentine pattern.

FINISHING PAINT KITS AND CAULKING:

Quality Stone has special color-matched 'Stone Finish' caulking and Touch-Up Paint Kits available for all Modern Brick colors. Paint should always go over Stone Finish caulking to ensure a long-term color match. Stone Finish caulking and/or touch-up paint must be used to cover exposed polyurethane, screw holes, damaged panels, or to add extra color.

You can use your finger to smooth and distribute the caulking once out of the gun, and Touch-Up Kits come with a small brush to work it in place. After a product edge is cut or trimmed, Stone Finish or Touch-Up Paint should be applied to the edge. When applying around door or window openings, exterior grade caulking may need to be applied according to local building codes. Check desired temperatures before applying any caulking, adhesives or finishing paint.

NOTE: Be sure to dust off any polyurethane dust from the product before applying the Stone Finish.

EXPANSION AND CONTRACTION: Polyurethane panels will have minimal expansion and contraction. However, it is recommended to install all Quality Stone products when they are cool (contracted state) and as tight as possible to minimize the visual appearance of expansion and contraction. Stone Finish and Quality Stone Paint Kits can be used to fill in any unwanted gaps for a seamless finish.

MAINTENANCE: Dirt and scum can be washed off the product surface with water and a non-scuffing cloth or sponge. Mild, non-abrasive household cleaners or soap can be used carefully with water clean stubborn materials or stains. If any finish is compromised, Stone Finish and Paint Kits can be used for all touch-ups and to re-finish.

www.qualitystoneproducts.com

*

Toll Free at 1-877-477-4373

*

Email at info@instoneproducts.ca